Table 1. Summary of sources of variation and quality indicators by pre-analytical phase.		
	Source of Variation	Quality Indicators (QIs)
Test Ordering	Similar test nameDuplicate ordersTranscription entry errorsVerbal orders misinterpreted	 Requests without clinical question Inappropriate requests with respect to clinical question Duplicate orders Requests with errors concerning test input orders
Patient Preparation	DietPostureExerciseTiming of sampling	Samples collected at inappropriate time
Sample Collection	 Patient Identification Sample labeling Needle size Sample volume Sample collection tube Inadequate tube filling IV Contamination Order of specimen draw Specimen clotting Fist clenching during phlebotomy 	 Requests with errors in patient ID Samples collected with inappropriate sample type Samples collected in inappropriate containers Samples with insufficient sample volume Samples with inappropriate volume to coagulant ratio Clotted samples Hemolyzed samples Lipemic samples Contaminated samples
Sample Processing, Transportation, and storage	 Agitation Delayed processing of outpatient clinic Re-centrifugation Exposure of samples to environment Add-on testing 	 Damaged samples Samples transported at inappropriate time Samples transported under inappropriate temperature conditions Improperly stored samples Samples lost or not received